

Grill cleaner

C 151

Alkaline heavy-duty cleaner for cookers, ovens and steamers

AREA OF APPLICATION:

- Suitable for cleaning of combination and hot-air steamers, convection ovens, grills and ovens.
- Powerfully removes grease, grill residues, burnt-in grease and food remnants of all kinds.
- Suitable for all stainless steel and cast iron surfaces.

For optimum cleaning of the areas around the dishwasher we recommend use of the Winterhalter Kitchen Hygiene range. The products are optimally matched to each other, and colour-coded.



PRODUCT ADVANTAGES:

- Highly concentrated
- Outstanding grease and dirt removal
- Good rinsability
- Extremely gentle on materials

DOSAGE:

Depending on the degree of soiling, spray undiluted or 10 % diluted (100 ml per 1 litre of water) onto the surface, leave it to work for a few minutes and then rinse off the loosened dirt with fresh water. For tough encrusted dirt, repeat the procedure or use a mechanical implement to aid cleaning as necessary.

INGREDIENTS:

Amphoteric tensides, alkalis, solubilisers



Grill cleaner

C 151

DELIVERY SIZES:

0,75 l	PE-bottle
10 l	PE-drum

TECHNICAL DATA:

Colour	brown
Odour	product-specific
pH value	approx. 14 (concentrated)
Shelf life	24 months
Storage conditions	cool, dark, frost-free to max. 30 °C
Density	approx. 1.1 g/cm ³

SAFETY NOTES:

H290	May be corrosive to metals.
H335	May cause respiratory irritation.
H314	Causes severe skin burns and eye damage.
P280	Wear protective gloves/protective clothing/eye protection/face protection.
P303+ P361+ P353	IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower.
P305+ P351+ P338	IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
P301+ P330+ P331	IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.
P304+ P340	IF INHALED: Remove person to fresh air and keep comfortable for breathing.
P310	Immediately call a POISON CENTER/doctor.
P501	Disposal in accordance with local regulations.

DISPOSAL OF EMPTY PACKAGING:

- Completely emptied packaging is recyclable and can be disposed of by the end user through the DSD (Duales System Deutschland GmbH).
- Information on disposal of product residues can be found in the safety data sheet.

IMPORTANT:

- Product is not intended for the general public. For commercial use only!
- Storage and transport permissible only in original packaging in upright position. Do not expose to direct sunlight. Protect from freezing.
- Never mix with other products and do not refill in other containers, bottles etc.!
- Colour variations in the product are caused by raw materials and storage and do not affect quality.
- For a comfortable use of the cleaner directly out of the 10 l canister a special sprayerset (Art-No. 3301563) incl. tube and screw cap is available.
- Drum spouts are available to aid filling the 1-litre containers from the 10litre refill containers.
- C 151 Grill Cleaner may only be used to clean surfaces with a maximum temperature of 70 °C.
- Always allow grill surfaces to cool before cleaning.
- C 151 is not suitable for pre-washing of dishes subsequently intended to be loaded into the dishwasher. To avoid unwanted foaming in the machine, Winterhalter Pre-cleaner A 50 PC should be used for the purpose.
- You will find this product's safety data sheet, technical data sheet and sample operating instructions on our homepage at www.winterhalter.biz